



Installation guide  
Solenoid valve  
Type EV227B

032R9277


032R9277




1




2




3



4



5



6

